


How to Change the Computer IP Address on the Scanner


1. Go to the "More" button.




2. Select "Maintenance".



3. Enter "1143" and press "Enter."



4. Click in the box and make the change.
Press "Save" when finished.



5. Select "Return to Scanner".

